infinity® ROOF LIGHT solutions by TuffX

Typical Installation - triple glazed | Option 1: Fixing from Externally














Installation Guide - triple glazed | Option 1: Fixing from Externally








100mm from each corner and then at regular intervals.






4 continuously all the way around securing the aluminium frame in place.

infinity® ROOF LIGHT solutions by TuffX

Typical Installation - triple glazed | Option 2: Fixing from Internally

Manufactured to: BS EN 12150 / BS EN 1279












Please note it is the responsibility of the customer to ensure that all products purchased and used are compliant with the Building Regulations.


Installation Guide - triple glazed | Option 2: Fixing from Internally





Triple Glazed | U-Value: 0.7 w/m2k
















Installation Guide - triple glazed | Option 1: Fixing from Externally








 ${\bf 3}^{\rm Pre \ drill \ fixing \ holes \ through \ aluminium \ and \ timber \ upstand/kerb \ at \ 100mm \ from \ each \ corner \ and \ then \ at \ regular \ intervals.}$






Secure fixing screws with horse shoe packers and finishing caps continuously all the way around securing the aluminium frame in place.

infinity® ROOF LIGHT solutions by TuffX

Typical Installation - triple glazed | Option 2: Fixing from Internally

Manufactured to: BS EN 12150 / BS EN 1279













Please note it is the responsibility of the customer to ensure that all products purchased and used are compliant with the Building Regulations.


Installation Guide - triple glazed | Option 2: Fixing from Internally









Pre drill fixing holes through aluminium and timber upstand/kerb at 100mm from each corner and then at regular intervals.





Triple Glazed | U-Value: 0.7 w/m2k














Triple Glazed | U-Value: 0.7 w/m2k
















Installation Guide - triple glazed | Option 1: Fixing from Externally








 ${\bf 3}^{\rm Pre \ drill \ fixing \ holes \ through \ aluminium \ and \ timber \ upstand/kerb \ at \ 100mm \ from \ each \ corner \ and \ then \ at \ regular \ intervals.}$






Secure fixing screws with horse shoe packers and finishing caps continuously all the way around securing the aluminium frame in place.

Triple Glazed | U-Value: 0.7 w/m2k














U-Value: 0.7 w/m2k
















Option 1 (Fixing from <u>Externally</u>) Fixed Rooflight Installation Guide

Fixed Flat Thermal Rooflight Typical Installation Guide



Please note it is the responsibility of the customer to ensure that all products purchased and used are compliant with Buildi ng Regulations